

TO USE THE SIGNAL TIMER - The signal timer will give you an alarm (buzz or chime) at the end of the set interval. To set the timer turn the knob, without depressing, in counter clockwise direction to the desired time interval. To turn off the alarm, turn knob until the pointer is at off.

TO SET THE TIME OF DAY. – Push knob in and turn clock hands in either direction.

TO SET INTERVAL TIME – Using knob turn interval timer hand in counter clockwise direction to desired time interval. At the end of time interval a buzzer will sound until hand is turned to “OFF”.

TO SET OVEN COOKING TIME - Using knob turn in either direction placing the hour you desire the cooking operation to “begin” in the window located above the knob. Next turn knob in either direction placing the hour you desire the cooking operation to “end” in the window located above this knob. After the timer has been programmed the cooking operation will delay until the time of day clock reaches the hour indicated in the start time window. At this point the cooking operation will start and continue until the clock reaches the hour indicated in the window marked stop time. Some timers have dials instead of windows and they should be set by pushing the knobs and turning the pointers to the desired start time and stop time.

NOTE: After the cooking cycle has ended it is necessary to either reset the time for additional cooking operations or return the timer to manual. This is done by pushing in on the stop time knob. **IMPORTANT – IF THE TIMER HAS NOT BEEN RETURNED TO MAUAL OR RESET FOR ANOTHER COOKING OPERATION THE OVEN WILL NOT FUNCTION.**

ROAST/BROIL TIMER

TO SET THE TIME OF DAY – Push knob in and turn clock hands in either direction.

TO SET INTERVAL TIME – Using knob turn interval timer hand in either direction to desired timer interval. At the end of time interval, a buzzer will sound until hand is turned to “OFF”.

TO DETERMINE ROASTING AND BROILING TIME – Using knob (3) or (4) turn pointer to type and weight of meat. Approximate “hours to cook” will appear in window opening.

FEATURES

THE LIFT – OFF OVEN DOOR

To remove, open the door about 3’ to the special broil stop position. Grasp the door at each side and lift straight up and off the hinges. **DO NOT IMMERSE THE OVEN DOOR IN WATER.**

TO REPLACE OVEN DOOR

Position slots in bottom of door over the hinges that are in the “out” position, then lower it slowly and evenly over both hinges at the same time.

NOTE: When removing or replacing the oven door be careful not to hit the door hinge with much force. It may snap closed against the front of the range. If this should happen you need only to pull the hinges to the open position before attempting to replace the door.

CAUTION: Do not place fingers behind hinges as this could result in injury.